

Raumtypen & Anforderung	Strong 956	Strong 745	Strong 738	Strong 733	Strong 966
Verwaltung					
Trittschalldämmung	●●●	●●●	●●●	●●●	●●●
Stuhlrolleneignung	●●●	●●●	●●●	●●●	●●●
Strapazierfähigkeit	●●●	●●●	●●●	●●●	●●●
Ästhetik	●●	●●	●●	●●	●●
Unterrichtsräume / Hörsaal					
Ästhetik, Atmosphäre	●●●	●●●	●●●	●●●	●●●
Strapazierfähigkeit	●●●	●●●	●●●	●●●	●●●
Trittschalldämmung	●●●	●●●	●●●	●●●	●●●
Schallabsorption	●●●	●●●	●●●	●●●	●●●
einfache Reinigung	●●	●●	●●	●●	●●
Fußwarme	●●●	●●●	●●●	●●●	●●●
Fachräume					
einfache Reinigung	●●	●●	●●	●●	●●
Stuhlrolleneignung	●●	●●	●●	●●	●●
ggf. Ableitfähigkeit	●●	●●	●●	●●	●●
Quellluftbodeneignung	●●●	●●●	●●●	●●●	●●●
Flurbereiche					
einfache Reinigung	●●	●●	●●	●●	●●
Strapazierfähigkeit	●●●	●●●	●●●	●●●	●●●
Trittschalldämmung	●●●	●●●	●●●	●●●	●●●
Lager					
Strapazierfähigkeit	●●●	●●●	●●●	●●●	●●●
Eindruck verhalten	●●●	●●●	●●●	●●●	●●●
einfache Reinigung	●●	●●	●●	●●	●●
Konferenzräume					
Ästhetik, Atmosphäre	●●	●●	●●	●●	●●
Strapazierfähigkeit	●●●	●●●	●●●	●●●	●●●
Trittschalldämmung	●●●	●●●	●●●	●●●	●●●
Schallabsorption	●●●	●●●	●●●	●●●	●●●
Eindruck verhalten	●●●	●●●	●●●	●●●	●●●
Stuhlrolleneignung	●●●	●●●	●●●	●●●	●●●
Eingangsbereiche					
einfache Reinigung	●●	●●	●●	●●	●●
Strapazierfähigkeit	●●	●●	●●	●●	●●
Ästhetik, Atmosphäre	●●	●●	●●	●●	●●
EDV-Bereiche					
Ableitfähigkeit	●●	●●	●●	●●	●●
Stuhlrolleneignung	●●●	●●●	●●●	●●●	●●●
Trittschalldämmung	●●●	●●●	●●●	●●●	●●●

- besonders empfohlen
- empfohlen
- nicht empfohlen

