

Rooms and Requirements	Strong 956	Strong 745	Strong 738	Strong 733	Strong 966
<b>Usage</b>					
Impact sound insulation	●●●	●●●	●●●	●●●	●●●
Durability	●●●	●●●	●●●	●●●	●●●
Castor chair suitability	●●●	●●●	●●●	●●●	●●●
<b>Halls and staircases</b>					
Impact sound insulation	●●●	●●●	●●●	●●●	●●●
Easy to clean	●●	●●	●●	●●	●●
<b>Entrance zones</b>					
Representativeness	●●	●●	●●	●●	●●
Aesthetics and atmosphere	●●	●●	●●	●●	●●
Durability	●●	●●	●●	●●	●●
<b>IT- rooms</b>					
Conductivity	●●	●●	●●	●●	●●
<b>Staff rooms</b>					
Durability	●●●	●●●	●●●	●●●	●●●
Castor chair suitability	●●●	●●●	●●●	●●●	●●●
Sound absorption	●●●	●●●	●●●	●●●	●●●
Aesthetics and atmosphere	●●●	●●●	●●●	●●●	●●●
Easy to clean	●●	●●	●●	●●	●●

- extremely recommended
- recommended
- not recommended

