

Raumtypen & Anforderung	Strong 956	Strong 745	Strong 738	Strong 733	Strong 966
Eingangsbereiche					
Ästhetik, Atmosphäre	●●	●●	●●	●●	●●
Strapazierfähigkeit	●●	●●	●●	●●	●●
einfache Reinigung	●●	●●	●●	●●	●●
Verkaufsräume					
Ästhetik, Atmosphäre	●●	●●	●●	●●	●●
Trittschalldämmung	●●	●●	●●	●●	●●
Schallabsorption	●●●	●●●	●●●	●●●	●●●
einfache Reinigung	●●	●●	●●	●●	●●
Strapazierfähigkeit	●●●	●●●	●●●	●●●	●●●
Pausenzonen					
einfache Reinigung	●●	●●	●●	●●	●●
Ästhetik	●●●	●●●	●●●	●●●	●●●
Strapazierfähigkeit	●●●	●●●	●●●	●●●	●●●
Flure / Treppenhäuser					
Strapazierfähigkeit	●●●	●●●	●●●	●●●	●●●
Trittschalldämmung	●●●	●●●	●●●	●●●	●●●
Lagerräume					
Strapazierfähigkeit	●●●	●●●	●●●	●●●	●●●
Eindruck verhalten	●●●	●●●	●●●	●●●	●●●
Bürobereiche					
Strapazierfähigkeit	●●●	●●●	●●●	●●●	●●●
Trittschalldämmung	●●●	●●●	●●●	●●●	●●●
Schallabsorption	●●●	●●●	●●●	●●●	●●●
Eindruck verhalten	●●●	●●●	●●●	●●●	●●●
Stuhlrolleneignung	●●●	●●●	●●●	●●●	●●●

- **besonders empfohlen**
- **empfohlen**
- **nicht empfohlen**

